

## Towmaster A Frame Checklist

### Assembly

1. Remove towing hole caps
2. Screw in towing pins
3. Attach A Frame to towing pins with L Pins and R clips
4. Attach 13 Pin lead to towed car socket
5. Attach breakaway cord to towed car
6. Manoeuvre car or motorhome into position
7. Attach A frame to motorhome towbar
8. Lock coupling if desired using optional lock
9. Attach 13 Pin lead to motorhome socket
10. Attach breakaway cord to motorhome towbar
11. Fit motorhome number plate to towed car
12. Position reflective triangle board in rear of tow car
13. Release car handbrake
14. Release car steering lock (do not put ignition on)
15. Ensure car is in neutral
16. If Pre 2015 Smart Car follow flat tow mode\*
17. Check towed car lights operation
18. If happy proceed to tow
19. Drive away gently allowing pin to lock out

#### Notes:

Do not set towed cars alarm

Avoid reversing unless absolutely necessary

### Disassembly

1. Put handbrake on in towed car
2. Remove breakaway cable
3. Remove 13 pin lead
4. Unlock and decouple hitch from motorhome
5. Press unlock buttons on Towmaster
6. Place hitch on ground and remove R clips and L pins
7. Unscrew towing pins and cover holes with caps
8. Remove triangles from rear window
9. Change number plate back to tow cars registration
10. Pack away Towmaster